

## PIG® HazMat Chemical Absorbent Pillow in Dispenser Box

PIL302 Absorbs Acids; Bases; Unknowns, Absorbs up to 30 oz. per pillow, 20 pillows

When the situation calls for more than a mat, our high-capacity HazMat pillows deliver the absorbency you need for highly concentrated corrosives.

- Absorbs the widest range of acids, bases and unknown liquids, even those with high concentrations like 98% sulfuric acid and 30% sodium hydroxide
- Chemical-resistant pillow won't degrade or cause a dangerous reaction upon contact with corrosive spills
- Pillow has large surface area, high capacity and fast-wicking filler to quickly soak up liquids; great for adding absorbency during spill response
- Polypropylene skin resists chemicals and tearing; reduces dust and holds in liquid, even when saturated
- Polypropylene filler is highly absorbent for containing corrosive or reactive spills
- Pink color is easily distinguishable to assure workers use the correct pillow during a spill emergency
- Can be incinerated after use to reduce waste
- Dispenser box makes pillows easy to access, carry and store while protecting contents from dirt and moisture



### Specifications

Fluid Absorbed	Acids; Bases; Unknowns
Color	Pink
Dimensions	8" W x 8" L x 1" H
Absorbency	Up to 4.69 gal. per case
Absorbency per	Up to 30 oz. per pillow
Sold as	20 pillows (2 boxes of 10 each)
Weight	7.5 lbs.
NSN (National Stock Number)	7920-01-369-5661

# per Pallet	45
Composition	Polypropylene
Includes	2 - PIG® HAZ-MAT Pillows (PIL306)
UNSPSC	47131908
UV Resistant	No
Pigalog® Page Number	<u>Page 75</u>

## Metric Equivalent

Absorbency per	Up to 887.1 mL per pillow
Absorbency	Up to 17.8 L per case
Dimensions	20.3cm W x 20.3cm L x 2.5cm H
Weight	3.4 kg

## Technical Information

### Technical Documents

[PIG Hazardous Chemical Absorbents](#)

[PIG® HAZ-MAT Absorbents](#)

[29 CFR 1910.22\(a\)\(2\)](#)

### Disclaimers

#### HAZ-MAT Notice

To ensure effectiveness and your safety, we recommend that you conduct compatibility and absorption testing of your chemicals with PIG® HAZ-MAT products prior to purchase. If you have any questions or need samples to test, please call Technical Services.



**One Pork Avenue • Tipton, PA 16684-0304**

1-855-493-4647 • Fax: 1-800-621-7447 • [newpig.com](http://newpig.com) • [hothogs@newpig.com](mailto:hothogs@newpig.com)